



Anziehvorschrift für Zylinderkopf		572.490 passend für / suitable for adaptable à / adaptable a Opel	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
 125.920 M 8x1,25x119			
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤ ➤	Pos. 1-10: 25 Nm Pos. 1-10: 60° Pos. 1-10: 60° Pos. 1-10: 60°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden Wärmelauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor Ø: 74 mm; $\frac{1}{8}$: 0,57 mm Mot: Z10XEP 1.0 ltr. (44 kW, 60 PS) Opel Agila, Corsa C, Corsa D Suzuki Wagon			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*572.490*	