







You know the following situation: With some new models of water flanges for VW it is not possible anymore to assemble the heat valve using the old screws. New in the aftermarket:

febi water flanges incl. screws suitable for VW Polo 2 / Golf 2 / Jetta 2 / Seat Cordoba / Vario, Ibiza

febi no. 14506, 22746, 18248 and 18222 Comparison no. 030 121 117 L, 030 121 117 N, 030 121 117 M, 032 121 121 J Screw febi no. 23592 / comparison no. N 906 298 01

The old models provide of pressed in brass sockets for the fastening of the flanges. These brass bushes provide of a thread to fasten the cover on the heat valve. This means that the old screws cannot be used for the new models.

Thus, only febi offers the new models with the appropriate screws. This means that the customer does not have to buy both parts separately but can immediately begin with the installation of the flange.

Please ask your febi partner for spare parts by febi bilstein! You will also find all spare parts at www.febi.com.

www.febi.com

