



## Achtung! Einstellbarer Bremslichtschalter!

Vor der Montage muss der innere Stoppring durch das Hochschieben der roten Sperre entsichert und der schwarze Pin soweit wie möglich herausgezogen werden (Spannreich 60mm - max. 73mm, siehe Zeichnung). Anschließend muss der rote Sperrschalter wieder herunter gedrückt werden, damit der innere Stoppring aktiviert ist. Während der Montage des febi Bremslichtschalters ist es notwendig, dass das Bremspedal bis zum maximalen Punkt durchgedrückt ist. Der Bremslichtschalter passt sich automatisch dem Pedal an und nimmt die richtige Stellung ein.





## Attention! Adjustable brake light switch!

Prior to assembly, the inner stop ring must be unlocked by pushing up the red locking collar with the black pin pulled out as far as possible (extended length 60mm - max. 73mm, see drawing). The red locking collar must then be pushed down again, so that the inner stop ring is activated. During the assembly of the febi brake light switch, the brake pedal must be pushed down as far as it will go. The brake light switch length is then automatically adjusted when the pedal returns to its normal position.

